

FRUCTOMAT - Recommended settings  
 Concentrat in sec.  
 Stand: 03.04.2007

**Concentrates**

Flowing pressure during preparation 1,5bar

**All values valid for program version MD02.00 and with new Interelektrik valves, starting from Serial Number MDIS+1312!**

Sirup	Cup size 900ml			Cup size 300ml			Cup size 250ml			Cup size 200ml			Wagner funnel sec./100ml	Indicator 1.5bar/300ml sucking pressure	Brix at 1:20
	Syrup time (sec.) 1:20	Syrup time (sec.) 1:30	Water time (sec.)	Syrup time (sec.) 1:20	Syrup time (sec.) 1:30	Water time (sec.)	Syrup time (sec.) 1:20	Syrup time (sec.) 1:30	Water time (sec.)	Syrup time (sec.) 1:20	Syrup time (sec.) 1:30	Water time (sec.)			
Apple	4,9	3,9	22,5	1,6	1,3	7,5	1,4	1,1	6,2	1,1	0,9	5,0	11,4 sec. / 220ml		2,7
Cola	4,9	3,9	22,5	1,6	1,3	7,5	1,4	1,1	6,2	1,1	0,9	5,0	11,5 sec.		2,7
Iced-Tea Peach	4,9	3,9	22,5	1,6	1,3	7,5	1,4	1,1	6,2	1,1	0,9	5,0	13 sec.		2,8
Black Currant	4,9	3,9	22,5	1,6	1,3	7,5	1,4	1,1	6,2	1,1	0,9	5,0	10 sec.	11,8ml	1,5
Cherry	4,9	3,9	22,5	1,6	1,3	7,5	1,4	1,1	6,2	1,1	0,9	5,0	10 sec.		1,7
Pear-Balm	4,9	3,9	22,5	1,6	1,3	7,5	1,4	1,1	6,2	1,1	0,9	5,0			1,8
Pineapple	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	26,9 sec.		2,3
Citrus isotonic	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	23,7 sec.		1,8
Multivitamin	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	26,7 sec.		2,1
Orange	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	25,3 sec.	11,1ml	2,6
ACE	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	25,3 sec.		1,9
Blood Orange	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	25,3 sec.		1,7
Grapefruit	9,0	-	22,5	3,0	-	7,5	2,5	-	6,2	2,0	-	5,0	25,3 sec.		2,1
Apple light	-	2,2	22,5	-	0,7	7,5	-	0,6	6,2	-	0,5	5,0			0,7
Orange light	-	2,2	22,5	-	0,7	7,5	-	0,6	6,2	-	0,5	5,0			0,7
Black Currant light	-	2,2	22,5	-	0,7	7,5	-	0,6	6,2	-	0,5	5,0			0,7
Grapefruit light	-	2,2	22,5	-	0,7	7,5	-	0,6	6,2	-	0,5	5,0			0,7
Water			22,5			7,5			6,2			5,0	10 sec. / 180ml		

**Info:**all numbers are recommended values (in cup size 300ml / 1:20 15ml concentrate should be sucked in – for actual value see indicator)